

Figure 1

FIG. 4 is a perspective view of a handheld electronic device 400, such as a PDA, showing a screen 406 displaying a menu of applications. The device 400 includes a display screen 406, a keypad 404, and various ports and buttons. The screen 406 shows a time display of 3:07 pm, a battery level indicator, and a list of applications including Address, Calc, Date Book, Expense, Graffiti, HotSync, Mail, Memo Pad, Prefs, Security, The Scan, and To Do List. The keypad 404 includes a home button, a search button, and a numeric keypad. The device 400 also features a camera 430 at the top, a speaker 432, and various ports and buttons on the sides and bottom.




Figure 4




Figure 2




Figure 3



Figure 5




Figure 6




Figure 7






Figure 8






Figure 9




Figure 10




Figure 11



Figure 12






Figure 13




Figure 14




Figure 15






Figure 16